# FLUKE 70 Series Multimeters

Service Manual

P/N 731034

January 1984 Rev. 1, 5/89

1989 John Fluke Mig. Co., Inc., All rights reserved. Litho in U.S.A.

FLUKE




Figure 3-1. Overview




Figure 3-2. Ohms Function

### Fluke 70 Series

 Referring to Table 4-4, set the Decade Resistor or Fluke 5100B to the resistance value indicated in steps 1 through 6. Verify that the display reading is within the limits shown.

### 4-11. Diode Test

To test the 75 and 77 meters, perform the following steps:

I. Put the UUT in the Diode Test function.

### NOTE

On Fluke 5100 series calibrators, activate the  $50\Omega$  divider override.

- Apply an input from the DC Voltage Calibrator of +.090V dc to the V-Ohm and Common input terminals of the UUT and verify that the beeper is on.
- Increase the DC Voltage Calibrator output to +.110V dc and verify that the beeper is off.

To test the 73 meter, apply an input from the DC Voltage Calibrator of +2V dc to the V-Ohm and Common input terminals of the UUT. Verify that the display reading is between +1.960 and +2.040.

### 4-12. DC mA Test (75 & 77 Only)

- Set the output of the DC Current Calibrator to zero and connect it to the 300 mA and Common input terminals of the UUT.
- Set the DC Current Calibrator to the output shown in Table 4-5, and verify that the UUT display reading is within the limits shown.

### 4-13. DC Amps Test

- Set the DC Current Calibrator for zero output and connect it to the 10A & Common input terminals of the UUT.
- Apply currents as indicated in Table 4-6 and verify the display reading is within the limits shown.

Table 4-2. AC Voltage Test

0.755	INP	UT		DISPLAY READING	The same
STEP	VOLTAGE	FREQ.	73	75	77
1	2.7V	100 Hz	2.617 to 2.783	2.644 to 2.756	2.644 to 2.756
- 2	2.7V	500 Hz	2.617 to 2.783	2.644 to 2.756	2.644 to 2.756
3	750V	100 Hz	725 to 775	733 to 767	733 to 767
4	750V	1000 Hz	725 to 775	733 to 767	733 to 767

### Table 4-3. DC Voltage Test

STEP	DC INPUT		DISPLAY READING	
	VOLTAGE	73	75	77
1	+2.7V	2.680 to 2.720	2.685 to 2.715	2.691 to 2.709
2	+27V	26.80 to 27.20	26.85 to 27.15	26.91 to 27.09
3	+270V	268.0 to 272.0	268.5 to 271.5	269.1 to 270.9
4	+1000V	991 to 1009	993 to 1007	995 to 1005
5*	+300 mV	297.8 to 302.2	298.4 to 301.6	299.0 to 301.0

### Table 4-4. Resistance Test

STEP	INPUT		DISPLAY READING	
SIEP	RESISTANCE	73	75	77
1	100Ω	98.8 to 101.2	99.1 to 100.9	99.3 to 100.7
2	1000Ω	989 to 1011	992 to 1008	994 to 1006
3	10 kΩ	9.89 to 10.11	9.92 to 10.08	9.94 to 10.06
4	100 kΩ	98.9 to 101.1	99.2 to 100.8	99.4 to 100.6
5	1 ΜΩ	.989 to 1.011	.992 to 1.008	.994 to 1.006
6	10 ΜΩ	9.69 to 10.31	9.74 to 10.26	9.79 to 10.21

Table 4-5. DC mA Test

CTED	INPUT	DISPLAY READING
STEP	CURRENT	75 & 77
1	+27 mA	26.58 to 27.43
2	+200 mA	195.8 to 204.2

Table 4-6. DC Amps Test

STEP	INPUT	DISPLAY	READING
	(5100B)	73	75 & 77
1	+1.99999A dc	1.94 to 2.06	1.95 to 2.05

### 4-14. CALIBRATION

- Set the DC Voltage Calibrator to zero and set the UUT to the VDC function.
- Connect the DC Voltage Calibrator to the V-Ohm and Common input terminals of the UUT.
- Set the DC Voltage Calibrator for an output of +3V dc and adjust R8 for a display reading of +3.000V dc ± .001V.

### 4-15. TROUBLESHOOTING

A fault guide for the 70 Series Multimeters is given in Table 4-7. This guide can be helpful in isolating troubles to a component area. Also, procedures are given below to help isolate the troubles further. In these procedures, the 70 Series Multimeter is referred to as the unit under test (UUT).

When troubleshooting the 70 Series Multimeters, use the precautions listed on the static awareness sheet to prevent damage from static discharge.

### 4-16. Overall System Check

Make the following checks in the order listed. All measurements are made with respect to common.

- Put the UUT function switch in the VDC position.
- Using a DVM, check +VDD (TP-1) or the positive battery post for 3.1V dc ± .1V.

Probable failure: BT1, CR1, U1, loose battery connector

 Connect an oscilloscope or counter to pin 54 of U1 or to the junction of C12 and Y1 crystal. Check for a 32.768 kHz sine wave approximately 600 mV p-p in amplitude. Note that U2 and the display will not work if the clock circuit is not working.

Probable failure: U1, Y1, or C12

 Check for a reference voltage of 1.00V dc (adjustable by R8) at pin 14 of U1 or the junction of R15 and R16.

Probable failure: R8, R14, R15, R16, VR1, or CR2

 Check that VM (V middle) is 1.6V dc ± .1V at pin 28 of U2 or at the junction of R11 and R12.

Probable failure: R11, R12 or C10

### 4-17. VDC Signal Tracing

Make the following checks in the order listed. All measurements are made with respect to common.

- Put the UUT in the VDC function and apply 2V dc to the input.
- Using a DVM, measure the input at J1 for 2V dc.
- 3. Measure pin 1 of Z1 input divider for 2V dc.

Probable failure: R1, S1, E1

### WARNING

R1 IS A FUSIBLE RESISTOR. TO ENSURE SAFETY, USE EXACT REPLACEMENT ONLY.

### NOTE

Measurements in steps 4, 5, and 6 may be affected by loading.

4. Measure Z1 pin 3 for 200 mV dc.

Probable failure: Z1, U1

Measure for 200 mV dc at the active filter input (AFI, pin 26 of U1 or R9).

Probable failure: U1

 Measure for 200 mV at the active filter output (AFO, pin 27 of U1 or R9).

Probable failure: R9, C5 or C6

Table 4-7. Fault Guide

SYMPTOM	ACTION	POSSIBLE COMPONENT
Blank display	Follow overall system check (paragraph 4-16)	BT1, U1, U2, Y1, CR1, C12
Display reads zero in volts function	Trace DC signal (paragraph 4-17)	E1, R1, Z1, R9, U1, S1
Display hangs up in power- up self test (see Figure 4-2)	Follow overall system check (paragraph 4-16)	R14, R8, R15, R16, VR1, C7, C8, Z1, CR2, U1
Display reads OL or zero in 300mA		R13, U1
Display reads zero in 300mA or 10A current ranges		F1, F3, R5, R13, R20
AC volts is not accurate		R17 & R18
Display reads OL in 300mV range		Q3 shorted, U1
AC volts noisy at 50 to 60 Hz		R9, R10, C5, C6
Display has wrong annunciator called	Check Table 3-1 for correct codes	S1 REAR, U1
Volts inaccurate		Check calibration
Ohms inaccurate		Z1, U1
Intermittent display	Clean connectors and connector strips of the LCD and pca	Display assembly
Display reads constant offset in volts		C5, C6, or C7 shorted
Ohms reads low or won't read OL		Q1 or Q2 shorted or leaky, E1, E2
Ohms reads randomly or flashes between on-scale and OL		R1, RT1

Table 5-1. 73 Final Assembly (See Figure 5-1.)

REF DES ITEM NO	DESCRIPTION	PART NUMBER	MFRS SPLY CODE	MANUFACTURER'S PART NUMBER	QTY
101	Case, Bottom Assembly	828608	89536	828608	1
102	Shield, Bottom	748236	89536	748236	1
111	Spring, Coil, Comp	697227	83553	C0360-026-0500	1
116	Screw, Thd form, 4-24x1/4	519116	COMMER		1
201	Case, Top Assembly	828624	89536	828624	1
202	Shield, Top	819300	89536	819300	1
203	Screw, Thd form, 2-14x.375	821140	COMMER	RCIAL	1
206	Window, LCD	642082	89536	642082	1
207	Bracket, LCD	646653	89536	646653	1
208	Mask, Bracket	642090	89536	642090	1
209	Conn, LCD/PCA, Elastomeric	649632	89536	649632	2
216	Screw, Thd form, 4-14x3/8	448456	COMMER	RCIAL	4
221	Knob, Switch	661033	89536	661033	1
222	Shaft, Knob	646661	89536	646661	1
223	Spring, Detent	646679	89536	646679	1
226	Shock Absorber	428441	89536	428441	1
241	Screw, Thd form, 5-14x3/4	733410	COMMER	CIAL	4
246	Foot, Non-skid	640565	89536	640565	24
301	Decal	828517	89536	828517	1
302	Label, Window - Fluke/Philips	844340	89536	844340	10
U3	LCD, 3.75 digit, Bar Graph	640581	18520	LF-7031G	1
N.S.	Screw, Thd form, 5-14x3/4	733410	COMMER	CIAL	4
N.S.	Decal, Warning	828707	89536	828707	1
N.S.	Decal, Warning	828715	89536	828715	1
N.S.	Fluke 73 Operator's Manual	704601	89536	704601	1
N.S.	TL70 Test Leads	642033	89536	642033	1
		The state of the s		parameter and the second	

N.S. = NOT SHOWN

### WARNING

FOR SAFETY PURPOSES, CASE TOPS AND CASE BOTTOMS SHOULD NOT BE INTERCHANGED BETWEEN PCA TYPES (i.e., DO NOT USE THE CASE TOP SPECIFIED FOR THE 7X-3001 ON THE 7X-3011, ETC.)




Figure 5-1. Final Assembly

## Table 5-4. 73 A1 Main PCA (See Figure 5-2.)

REF DES ITEM NO	DESCRIPTION	PART NUMBER	MFRS SPLY CODE	MANUFACTURER'S PART NUMBER	QTY
BT 1	Battery, Primary, 9V	696534	66571	216	1
C1	Cap, Poly, .022uF, 1000V, 10%	721019	60935		1
C2,C10	Cap, Tant, .47uF, 35V, 20	655035	56289	199D474X0035AA1	2
C4	Cap, Alum, 2.2uF, 50V, 20%	650069	62643		
C5,C6	Cap, Polyca, .027uF, 63V, 10%	720979	65964		2
C7	Cap, Polyes, .47uF, 50V, 10%	697409			1
C8	Cap, Polypr, .033uF, 63V, 10	721050	60935		1
C9	Cap, Tant, 6.8uF, 10V, 20%	655043	56289		1
C11	Cap, Tant, 2.2uF, 16V, 20%	706804	56289		1
C12 C13	Cap, Cer, 47pF, 50V, 20%	706705	72982 72982		1
C14,C15	Cap, Cer, .22uF, 50V, +80%-20% Cap, Cer, 33pF, 50V, 5%	733386 714543	72982	RPE122Z5U224Z50V RPE113C0G330350V	1 2
CR1,CR2	Diode, Radial Insert	659516	09214	1N4448	2
E1,E2	Surge Protector, 1500V	655134	91984	100	2
F3	Fuse, Fast, 15A, 600V	820829	71400		1
J1-4	Receptacle, Input	642959	89536		3
Q1,Q3	Xstr, Sm Signal	685404	04713		3 2
Q2	Xstr, Sm Signal	698225	04713		1
	Res, MF, 1K, Fusible, 2%	854687	23237		1
R2,R3	Res, Cer, 1M, 1W, 5%	655175	23237		2
R4	Res, CF, 100k, 1/4W, 5%	658963	59124		1
R5	Res, CF, 390k, 1/4W, 5%		59124		1
R7 R8	Res, WW, .005, .5W, 1% Res, Cer, Var, 100k, .3W, 20%	740415 649897	05347 51406		1
R9,R19	Res, CF, 1M, 1/4W, 5%	649970	59124		2
R10	Res, CF, 1.5M, 1/4W, 5%	649962	59124	1-4-5P155J	1
R11	Res, MF, 332k, 1/8W, 1%	655217	59124	MFF1-83323F	1
R12	Res, MF, 301k, 1/8W, 1%	655274	59124	MFF1-83013F	1
R14	Res, CF, 62k, 1/4W, 5%	713941	59124		1
R15	Res, MF, 56.2k, 1/8W, 1%	706242	59124	MF50D5622F	1
R16	Res, MF, 205k, 1/8W, 1%	706234	59124	MF50D5622F	1
R17	Res, MF, 20.5k, 1/8W, .5%	682716	59124	MF50D2052D	1:
R18	Res, MF, 9.20k, 1/8W, .5%	715219	59124		1
RJ1	Varistor, 430V, 1mA, 10%	706838	09214	V264LAX1398 ·	1
RT1	Thermistor, Pos, 1k, 40%, 25C	446849	54583	911P84E102YU13	1
S1	Switch, Rotary	642918	89536		1
U1 U2	8075 A/D Chip Tested	683052	89536		1
VR1	IC, CMOS, SM-5A, 4-Bit Micro Bandgap, Taped	659656 729202	18520 89536		1
W3,W4	Res, Jumper, .25W, .02 ohm	682575	09969		2
W5	Wire Jumper, PVC Insul.	747394	89536	747394	1
Y 1	Crystal, 32.768 kHz, 3x8mm, 1%	643031	61429		1
21	Input Divider Network	683789	89536		1
N.S.	Contact, 600V Fuse	707190	89536	707190	2
N.S.	Contact, Battery (Female)	654228	89536		1
N.S.	Contact, Battery (Male)	642967	89536	642967	1

N.S. = NOT SHOWN

<sup>\*</sup> WARNING--Fusible Resistor. To ensure safety, use exact replacement only.

Table 5-5. 75 A1 Main PCA (See Figure 5-2.)

	(See Figure		MFRS		
REF DES	DESCRIPTION	PART NUMBER	SPLY	MANUFACTURER'S PART NUMBER	QTY
BT1	Battery, Primary, 9V	696534	66571	216	1
C1	Cap, Poly, .022uF, 1000V, 10%	721019	60935	MKT-1.60	1
C2,C10	Cap, Tant, .47uF, 35V, 20	655035	56289	199D474X0035AA1	2
C4	Cap, Alum, 2.2uF, 50V, 20%	650069	62643		
C5,C6	Cap, Polyca, .027uF, 63V, 10%	720979	65964		
C7	Cap, Polyes, .47uF, 50V, 10%	697409	60935		1
C8	Cap, Polypr, .033uF, 63V, 10	721050	60935		1
C9	Cap, Tant, 6.8uF, 10V, 20%	655043	56289		1
C11	Cap, Tant, 2.2uF, 16V, 20%	706804	56289		1
C12	Cap, Cer, 47pF, 50V, 20%	706705	72982		1
C13	Cap, Cer, .22uF, 50V, +80%-20%	733386	72982		1
C14,C15	Cap, Cer, 33pF, 50V, 5%	714543	72982	RPE113COG330350V	2
CR1,CR2	Diode, Radial Insert	659516	09214	1N4448	2
E1,E2	Surge Protector, 1500V	655134	91984	100	2
F1	Fuse, 5x20mm, .63A, 250V	740670	71400		2 1 4
F3	Fuse, Fast, 15A, 600V	820829	71400	KTK-15	1
J1-4	Receptacle, Input	642959	89536	642959	Ji.
Q1,Q3	Xstr, Sm Signal	685404	04713		2
Q2 Q2	Xstr, Sm Signal	698225			1
	Res, MF, 1K, Fusible, 2%	854687		2N3904RLRA2 FA8466	1
R2,R3			23237		2
R4	Res, Cer, 1M, 1W, 5%	655175	23237	RG1/2-105M-5%	-
R5	Res, CF, 100k, 1/4W, 5%	658963		1-4-5P104K CRB14CXE	= ;
R6	Res, MF, 402k, 1/4w, .25%	706739	57668		1
R7	Res, 4.99, 2.5W, 1% Res, WW, .005, .5W, 1%	655019 740415		NS-2C4R99F RCS02R0053F	4
R8		649897			1
R9,R19	Res, Cer, Var, 100k, .3W, 20% Res, CF, 1M, 1/4W, 5%	649970		RVS0707V1003104M	2
R10		649962		1-4-5P105J	1
R11	Res, CF, 1.5M, 1/4W, 5%	655217		1-4-5P155J	1
R12	Res, MF, 332k, 1/8W, 1%	655274		MFF1-83323F	1
R13	Res, MF, 301k, 1/8W, 1%	706747		MFF1-83013F MF50D4482C	1
R14	Res, MF, 44.8k, 1/8W, .25% Res, CF, 62k, 1/4W, 5%	713941	59124 59124		1
R15	Res, MF, 56.2k, 1/8W, 1%	706242		CF1-4VT623J,REEL MF50D5622F	1
R16	Res, MF, 205k, 1/8W, 1%	706242			1
R17	Res, MF, 20.5k, 1/8W, .5%	682716		MF50D5622F	1
R18				MF50D2052D	1
	Res, MF, 9.20k, 1/8W, .5%	715219		MF50D9201D SPF3605	1
RJ1	Res, WW, Fusible, .36, 2W	740662			1
	Varistor, 430V, 1mA, 10%	706838		V264LAX1398	
RT1	Thermistor, Pos, 1k, 40%, 25C	446849		911P84E102YU13	1
S1	Switch, Rotary	642918		642918	1
U1	8075 A/D Chip Tested	683052		683052	1
U2	IC, CMOS, SM-5A, 4-Bit Micro	659656		LR3676	1
VR1	Bandgap, Taped	729202	89536	729202	1
W1	Res, Jumper, .25W, .02	682575		FRJ-55	1
W5	Wire Jumper, PVC Insul.	747394	89536	747394	1
Y 1	Crystal, 32.768 kHz, 3x8mm, 1%	643031	61429	NC38	1
21	Input Divider Network	616870	89536	616870	1
N.S.	250V Fuse, Hldr, 5mmx20mm	697086	61857	H-0011-2	2
N.S.	Contact, 600V Fuse	707190	89536	707190	
N.S.	Contact, Battery (Female)	654228	89536	654228	1
N.S.	Contact, Battery (Male)	642967	89536	642967	1

N.S. = NOT SHOWN

<sup>\*</sup> WARNING--Fusible Resistor. To ensure safety, use exact replacement only.

### Table 5-6. 77 A1 Main PCA (See Figure 5-2.)

REF DES	DESCRIPTION	PART	MFRS SPLY CODE	MANUFACTURER'S PART NUMBER	QT
BT1	Battery, Primary, 9V	696534	66571	216	1
C2,C10	Cap, Tant, .47uF, 35V, 20	655035	56289		2
24	Cap, Alum, 2.2uF, 50V, 20%	650069	62643		
5,C6	Cap, Polyca, .027uF, 63V, 10%	720979	65964		2
7	Cap, Polyes, .47uF, 50V, 10%	697409	60935		1
8	Cap, Polypr, .033uF, 63V, 10	721050	60935		1
9	Cap, Tant, 6.8uF, 10V, 20% Cap, Tant, 2.2uF, 16V, 20%	655043 706804	56289 56289		1
11	Cap, Cer, 47pF, 50V, 20%	706705	72982		1
13	Cap, Cer, .22uF, 50V, +80%-20%	733386	72982		1
14,C15	Cap, Cer, 33pF, 50V, 5%	714543	72982		2
CR1,CR2	Diode, Radial Insert	659516	09214		2
1,E2	Surge Protector, 1500V	655134	91984	100	2
1	Fuse, 5x20mm, .63A, 250V	740670	71400		2
3	Fuse, Fast, 15A, 600V	820829	71400		1
11-4	Receptacle, Input	642959	89536		4
1,Q3	Xstr, Sm Signal	685404	04713		2
)2		698225	04713		1
	Res, MF, 1K, Fusible, 2%	854687	23237		2
2,R3	Res, Cer, 1M, 1W, 5%	655175	23237		1
4	Res, CF, 100k, 1/4W, 5%	658963	59124		1
5	Res, MF, 402k, 1/4w, .25%	706739 655019	09969	NS-2C4R99F	1
6 7	Res, 4.99, 2.5W, 1% Res, WW, .005, .5W, 1%	740415	05347		1
8	Res, Cer, Var, 100k; .3W, 20%	649897	51406		1
9,R19	Res CF 1M 1/4W 5%	649970		1-4-5P105J	2
10	Res, CF, 1M, 1/4W, 5% Res, CF, 1.5M, 1/4W, 5% Res, MF, 332k, 1/8W, 1%	649962	59124		1
11	Res. MF, 332k, 1/8W, 1%	655217	59124		
12	Res, MF, 301k, 1/8W, 1%	655274	59124	MFF1-83013F	1
13	Res, MF, 44.8k, 1/8W, .25%	706747	59124		1
14	Res, CF, 62k, 1/4W, 5%	713941	59124		1
15	Res, MF, 56.2k, 1/8W, 1%	706242	59124		1
16		706234	59124		1
17	Res, MF, 20.5k, 1/8W, .5%	682716	59124	MF50D2052D .	1
18	Res, MF, 9.20k, 1/8W, .5%				1
	Res, WW, Fusible, .36, 2W	740662	23237		1
J1	Varistor, 430V, 1mA, 10%	706838 446849	09214 54583		1
T 1 1	Thermistor, Pos, 1k, 40%, 25C Switch, Rotary	642918	89536		1
1	8075 A/D Chip Tested	683052	89536		1
2	IC, CMOS, SM-5A, 4-Bit Micro	659656	18520		1
R1	Bandgap, Taped	729202	89536		1
2	Res, Jumper, .25W, .02	682575	09969		1
5	Wire Jumper, PVC Insul.	747394	89536	747394	1
1	Crystal, 32.768 kHz, 3x8mm, 1%	643031	61429	NC38	1
1	Input Divider Network	683797	89536	683797	1
.S.	250V Fuse, Hldr, 5mmx20mm	697086	61857	H-0011-2	2
.S.	Contact, 600V Fuse	707190	89536	707190	2
.S.	Contact, Battery (Female)	654228	89536		1
I.S.	Contact, Battery (Male)	642967	89536	642967	1

<sup>\*</sup> WARNING--Fusible Resistor. To ensure safety, use exact replacement only.




Figure 5-2. A1 Main PCA

# Section 7 Schematic Diagram

### 7-1. INTRODUCTION

This section presents a schematic diagram for the Fluke 73, 75, and 77 Multimeters. Differences between the models are noted.

Table 7-1 contains a list of definitions for abbreviations used in the schematic drawing.

Table 7-1. Abbreviations

ABBREVIATION	DEFINITION
ACA	AC Converter Feedback
ACHI	AC Converter High
ACL	All Clear, Reset
ACLO	AC Converter Low
AFI	Active Filter Input
AFO	Active Filter Output
AMO	Amps Input
AM1	Amps Divide by 10
AZ	Auto Zero Point
BPR	Beeper Driver
ВТ	Battery
CLK	Clock Output
COM	Common
DCS	DC Sense

Table 7-1. Abbreviations (cont)

ABBREVIATION	DEFINITION
EC	Reference Voltage
FAO	Active Filter Amp Output
FA(-)	Active Filter Amp Feedback
INT	Integrator Output
K0	D. Was Divide Data Octob
K1	Buffer Divide By 1 Output Buffer Divide by 3 Output
LS	Loud Speaker
LO	Low
OHS	Ohms Sense
RNG	Range
RRS	Reference Resistor Sense
RT	Thermistor
VSS	Negative Supply Voltage
VDD	Positive Supply Voltage
VM	Volts Middle
ww	Wirewound
XTL	Crystal Oscillator Inputs
Z	Impedance




Figure 7-1. A1 Main PCA

Fluke 70 Series

# Section 8 Manual Change Information

The A1 Main PCA in your 70 Series Multimeter may be one of the following types: 7X-3021, 7X-3011, or 7X-3001. This manual currently documents all 70 Series instruments that have the 7X-3021 A1 Main PCA. Make the changes to your manual as described in the following pages if the A1 Main PCA in your instrument is either a 7X-3011 or a 7X-3001. The pca type is located under the battery on the top side of the pca.

### WARNING

FOR SAFETY PURPOSES, CASE TOPS AND CASE BOTTOMS SHOULD NOT BE INTERCHANGED BETWEEN PCA TYPES (i.e., DO NOT USE THE CASE TOP SPECIFIED FOR THE 7X-3001 ON THE 7X-3011, ETC.)

### CHANGE #1 (7X-3011)

Make the following changes to your manual to reflect the 7X-3011 type of A1 Main PCA:


Change the appropriate parts lists as follows:


DELETE: 202 Shield, Top 819300 203 Screw, Thd form, 2-14x.375 821140 F3 Fuse, Fast, 15A 600V 820829

Change the Case Top Assembly and Case Bottom Assembly part numbers:

	CASE TOP ASSEMBLY			CASE BOTTOM ASSEMBLY		
	73	75	77	73	75	77
FROM: TO:	828624 656116	828632 651752	828616 652552	828608 661009	828640 785238	828640 785238

Replace the 7X-1621 reference designator drawing with the 7X-1611.





### Fluke 70 Series

### CHANGE #2 (7X-3001)

Make the following changes to your manual to reflect the 7X-3001 version A1 Main PCA:

Change the appropriate parts lists as follows:

DELETE: 202 Shield, Top 819300 203 Screw, Thd form, 2-14x.375 821140 F3 Fuse, Fast, 15A 600V 820829 R20 Res, WW, Fusible, .36, 2W 740662 RJ1 Varistor, 430V, 1 mA, 10% 706838 ADD: F2 Fuse, Fiber, 3A, 600V 475004

Change the Case Top Assembly and Case Bottom Assembly part numbers:

CASE TOP ASSEMBLY CASE BOTTOM ASSEMBLY 73 77 75 73 75 77 FROM: 828624 828632 828616 828608 828640 828640 TO: 656116 651752 652552 661009 654095 654075 Replace the 7X-1621 reference designator drawing with the 7X-1601:

